


LifeFitness

ARCTIC SILVER 95CEZ Upright Bike



Customer Support Services
PARTS MANUAL rev 01 May 2008

ARCTIC SILVER 95CEZ
REFERENCES

95CEZ-0000-01
S/N CZE100000 and UP

OPERATION MANUAL	M051-00K63-A064
HARDWARE BAG	GK63-00002-0044
POWER OPTION KIT – 120V	GK63-00002-0005
POWER OPTION KIT – 220/50 UK	GK63-00002-0039
POWER OPTION KIT – 240V+ AUS	GK63-00002-0040
POWER OPTION KIT – 220/50	GK63-00002-0041
TOUCH UP PAINT: SPRAY CAN .5 OZ BOTTLE W/APPLICATOR .33 OZ PEN	0017-00008-0204 0017-00008-0205 0017-00008-0206
COAX CABLE	AK32-00020-0001
ER READY BRACKET ASSEMBLY ASEMBLY CONSISTS OF: 1) POWER CABLE 2) F TYPE CONNECTOR	AK63-00215-0000 AK32-00078-0001 0017-00021-2846
SERVICE MANUAL	M051-00K63-A009

ARCTIC SILVER 95CEZ

CONTENTS


95CEZ-0000-01
S/N CZE100000 and UP

	Page
Console and Related Components	4
Entertainment TV Console.....	5
Connector Bracket	6
Entertainment Mounting Bracket	7
Console Mounting Screws and Polar Covers	8
Alternator w/Pulley	9
Crankshaft and Bearing Assembly.....	10
Intermediate Shaft and Bearing Assembly.....	11
Seat Latch Assembly	12
Seat Post Assembly.....	13
Seat Post Shrouds.....	14
Idler Bracket Assembly	15
Console Support Assembly	16
Left Side Shroud and Crankarm	17
Right Side Shroud and Crankarm	18
PCB Mounting Bracket Assembly	19
Front Wheels	20
Resistor Assembly	21
Handlebar Assembly.....	22
Belts.....	23
Cables	24

ARCTIC SILVER 95CEZ

Console and Related Components

95CEZ-0000-01
S/N CZE100000 and UP




Part Number	. Console Assembly	Part Number	Bezel/Switch W/Overlay Assy
AK63-00251-0001	CONS-ASSY: 95CEZ; ENG	AK63-00250-0001	BZL/SW W/OVERLAY ASSY: MFG; 95CEZ/95REZ ENG
AK63-00251-0002	CONS-ASSY; 95CEZ; EUR		
AK63-00251-0003	CONS-ASSY; 95CEZ; GER	AK63-00250-0003	BZL/SW W/OVERLAY ASSY: 95CEZ/95REZ GER
AK63-00251-0004	CONS-ASSY; 95CEZ; SPN	AK63-00250-0004	BZL/SW W/OVERLAY ASSY: 95CEZ/95REZ SPN
AK63-00251-0006	CONS-ASSY; 95CEZ; JAP	AK63-00250-0006	BZL/SW W/OVERLAY ASSY: 95CEZ/95REZ JAP
AK63-00251-0007	CONS-ASSY; 95CEZ; FRN	AK63-00250-0007	BZL/SW W/OVERLAY ASSY: 95CEZ/95REZ FRN
AK63-00251-0008	CONS-ASSY; 95CEZ; ITL	AK63-00250-0008	BZL/SW W/OVERLAY ASSY: 95CEZ/95REZ ITL
AK63-00251-0009	CONS-ASSY; 95CEZ; DUT	AK63-00250-0009	BZL/SW W/OVERLAY ASSY: 95CEZ/95REZ DUT
AK63-00251-0010	CONS-ASSY; 95CEZ; POR	AK63-00250-0010	BZL/SW W/OVERLAY ASSY;; 95CEZ/95REZ POR
AK63-00251-0014	CONS-ASSY; 95CEZ; TUR		

ARCTIC SILVER 95CEZ

Console Mtg. Screws & Polar Covers

95CEZ-0000-01

S/N CZE100000 and UP




ARCTIC SILVER 95CEZ

Alternator w/Pulley-AK63-00093-0000


95CEZ-0000-01

S/N CZE100000 and UP



ARCTIC SILVER 95CEZ
Crankshaft and Bearing Assembly

95CEZ-0000-01
S/N CZE100000 and UP




ARCTIC SILVER 95CEZ

Intermediate Shaft and Bearing Assembly

95CEZ-0000-01

S/N CZE100000 and UP




ARCTIC SILVER 95CEZ

Seat Latch Assembly - AK63-00043-0001

95CEZ-0000-01

S/N CZE100000 and UP




ARCTIC SILVER 95CEZ

Seat Post Assembly – AK63-00232-0002



95CEZ-0000-01

S/N CZE100000 and UP




Left Seat Post Shroud
OK63-01092-0010

Screw
0017-00101-1741



Right Seat Post Shroud
OK63-01092-0009




ARCTIC SILVER 95CEZ

Console Support Assembly- AK63-00233-0006

95CEZ-0000-01

S/N CZE100000 and UP




ARCTIC SILVER 95CEZ

Left Side Shroud and Crankarm

95CEZ-0000-01

S/N CZE100000 and UP




ARCTIC SILVER 95CEZ

Right Side Shroud and Crankarm

95CEZ-0000-01


S/N CZE100000 and UP





ARCTIC SILVER 95CEZ
PCB Mounting Bracket Assembly

95CEZ-0000-01
S/N CZE100000 and UP

Assembly Number – AK63-00049-0000










ARCTIC SILVER 95CEZ

Handlebar Assembly - AK63-00091-0001

95CEZ-0000-01

S/N CZE100000 and UP





Cables

S/N CZE100000 and UP

